




























Originalfernbedienung Ersatzfernbedienung






Power		Power
Mute		Mute / Dimmer
1		1
2		2
3		3
4		4
5		5
6		6
7		7
8		8
9		9
0		0
Text		Text / Goto
Recall / S.Page		Back / Return
Index / PVR List		Smart / List
Reveal / Rec		Rec / Rec Mode
Zoom / T.Shift		Zoom / Size

Originalfernbedienung Ersatzfernbedienung


















Hold / Auto		Shift + Stop /
Hold / Auto		D.Menu / Top
Red		Red / Netflix / Search
Green		Green / APP / Repeat
Yellow		Yellow / YouTube / Repeat
Blue		Blue / Prime Video / Random
Vol +		Vol+
Vol -		Vol-
I - II		Audio / Lang I/II
Source		AV / Input / RDS
CH +		CH+ / Page+
Freeze		Shift + Pause / Step /
CH -		CH- / Page-
Sleep		Sleep / Timer
Menu		Menu / Home
Exit		Exit / Cancel / Clear
DTV / Radio		TV/Radio /




Originalfernbedienung Ersatzfernbedienung

Power		Power
Freeze		Pause / Step / Freeze
Swap		Back / Return
PIP		Eject / Surround
I-II		Audio / Lang I/II
FAV.CH		Fav / Marker / PC
[≡]		Text / Goto
Mute		Mute / Dimmer
Sleep		Sleep / Timer
P.Size		Zoom / Size
1		1
2		2
3		3
4		4
5		5
6		6
7		7

Originalfernbedienung Ersatzfernbedienung

8		8
9		9
0		0
Vol+		Vol+
Jump		Setup / OPT /
ENT		Smart / List
Vol-		Vol-
Info		Info / Angle
Source		AV / Input / RDS
CH+		CH+ / Page+
Ch-		CH- / Page-
Exit		Exit / Cancel / Clear
Menu		Menu / Home
Up		Up
Left		Left
OK		OK
Right		Right



