





































Originalfernbedienung Ersatzfernbedienung

|   |             |   |       |
|---|-------------|---|-------|
|    | Power       |    | Power |
|    | Muting      |    | Mute  |
|    | 1           |    | 1     |
|    | 2           |    | 2     |
|    | 3           |    | 3     |
|    | 4           |    | 4     |
|    | 5           |    | 5     |
|    | 6           |    | 6     |
|    | 7           |    | 7     |
|    | 8           |    | 8     |
|    | 9           |   | 9     |
|  | 10/0        |  | 0     |
|  | >10         |  | Guide |
|  | Clear       |  | Exit  |
|  | Preset Up   |  | Up    |
|  | Preset Down |  | Down  |
|  | >>I         |  | >>I   |

Originalfernbedienung Ersatzfernbedienung

|   |                 |   |              |
|---|-----------------|---|--------------|
|    | >>              |    | >>           |
|    | <<              |    | <<           |
|    | I<<             |    | I<<          |
|    | Enter           |    | Ok           |
|    | Treble          |    | Info         |
|    | Bass            |    | Back         |
|    | Repeat          |    | Text         |
|    | CD Play/Pause   |    | Play         |
|    | Tape <>         |    | Pause        |
|    | Stop            |    | Stop         |
|    | Tuner/Band      |    | TV/R         |
|  | Shuffle/Program |  | Options      |
|  | Function        |  | Menu         |
|  | Dimmer          |  | Smart        |
|  | Sleep           |  | Sleep        |
|  | Display         |  | Shift + Info |
|  | Volume+         |  | Vol +        |



