




































**Originalfernbedienung    Ersatzfernbedienung**

|   |       |   |                    |
|---|-------|---|--------------------|
|    | Power |    | Power              |
|    | Mute  |    | Mute / Dimmer      |
|    | 1     |    | 1                  |
|    | 2     |    | 2                  |
|    | 3     |    | 3                  |
|    | 4     |    | 4                  |
|    | 5     |    | 5                  |
|    | 6     |    | 6                  |
|    | 7     |    | 7                  |
|    | 8     |    | 8                  |
|   | 9     |   | 9                  |
|  | 0     |  | 0                  |
|  | -/--  |  | Guide / EPG / -/-- |
|  | AV    |  | AV / Input / RDS   |
|  | Menu  |  | Menu / Home        |
|  | Swap  |  | Back / Return      |
|  | OK    |  | OK                 |

**Originalfernbedienung    Ersatzfernbedienung**

|   |                    |   |                             |
|---|--------------------|---|-----------------------------|
|    | Up                 |    | Up                          |
|    | PR+                |    | CH+ / Page+                 |
|    | PR-                |    | CH- / Page-                 |
|    | Down               |    | Down                        |
|    | Right              |    | Right                       |
|    | Vol+               |    | Vol+                        |
|    | Left               |    | Left                        |
|    | Vol-               |    | Vol-                        |
|    | TV/TX              |    | Text / Goto                 |
|    | PP                 |    | Fav / Marker / PC           |
|   | 16:9               |   | Setup / OPT /               |
|  | Red                |  | Red / Netflix / Search      |
|  | Green              |  | Green / APP / Repeat        |
|  | Yellow             |  | Yellow / YouTube / Repeat   |
|  | Blue               |  | Blue / Prime Video / Random |
|  | Violet             |  | Display / Media             |
|  | [ ] Smart Controls |  | Picture / Format            |



