



Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	Red/F1		Red
	Green/F2		Green
	Yellow/F3		Yellow
	Blue/IPTV		Blue
	<<		<<
	Play		Play
	Pause		Pause
	Stop		Stop
	>>		>>
	V.Format		Format
	Resolution		3D
	Subtitle		Subt
	Rec		Rec
	Option		Options
	Audio		Dual

Originalfernbedienung Ersatzfernbedienung

	Text		Text
	SAT		Smart
	Info		Info
	Recall		Back
	Menu		Menu
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	FAV		Pre Ch
	EPG		Guide
	Page+		Ch +
	Page-		Ch -



