



































Originalfernbedienung Ersatzfernbedienung

|   |        |   |                   |
|---|--------|---|-------------------|
|    | Mute   |    | Mute / Dimmer     |
|    | Power  |    | Power             |
|    | Prog   |    | TV/Radio /        |
|    | I-II   |    | Audio / Lang I/II |
|    | O to O |    | Sound / Title     |
|    | PP     |    | Back / Return     |
|    | 1      |    | 1                 |
|    | 2      |    | 2                 |
|    | 3      |    | 3                 |
|    | 4      |    | 4                 |
|  | 5      |  | 5                 |
|  | 6      |  | 6                 |
|  | 7      |  | 7                 |
|  | 8      |  | 8                 |
|  | 9      |  | 9                 |
|  | 0      |  | 0                 |
|  | --     |  | Guide / EPG / --  |

Originalfernbedienung Ersatzfernbedienung

|   |                |   |                             |
|---|----------------|---|-----------------------------|
|    | ZAP            |    | Smart / List                |
|    | Up / P+        |    | Up                          |
|    | Up / P+        |    | CH+ / Page+                 |
|    | Right / Vol+   |    | Right                       |
|    | Right / Vol+   |    | Vol+                        |
|    | Left / Vol-    |    | Left                        |
|    | Left / Vol-    |    | Vol-                        |
|    | Normal         |    | OK                          |
|    | Down / P-      |    | Down                        |
|    | Down / P-      |    | CH- / Page-                 |
|  | Red / Memo     |  | Red / Netflix / Search      |
|  | Green / Audio  |  | Green / APP / Repeat        |
|  | Green / Audio  |  | Shift + Audio / Lang I/II   |
|  | Yellow / Video |  | Yellow / YouTube / Repeat   |
|  | Blue / Extra   |  | Blue / Prime Video / Random |
|  | [ ]            |  | Display / Media             |
|  | [ + ]          |  | Stop / Hold                 |



