






































































Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|----------|---|-------|
|  | Power |  | Power |
|  | Mute |  | Mute |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | -/--/--- |  | Guide |
|  | Swap |  | Back |
|  | TV/AV |  | AV |
|  | Game |  | Smart |
|  | Text |  | Text |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|---------------|---|--------------|
|  | Menu |  | Menu |
|  | P.Std |  | Format |
|  | S.Std |  | Dual |
|  | P+ |  | Ch + |
|  | P+ |  | Up |
|  | P- |  | Ch - |
|  | P- |  | Down |
|  | V+ |  | Vol + |
|  | V+ |  | Right |
|  | V- |  | Vol - |
|  | V- |  | Left |
|  | Red / Picture |  | Red |
|  | Green / Sound |  | Green |
|  | Green / Sound |  | Shift + Dual |
|  | Yellow / Time |  | Yellow |
|  | Blue / Setup |  | Blue |
|  | Blue / Setup |  | Options |



