




Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|---------------|---|--------------|
|  | On / Off |  | Power |
|  | Mute All |  | Shift + Mute |
|  | Mute |  | Mute |
|  | Stored |  | List |
|  | CD - DVD |  | Shift + 1 |
|  | FM - AM |  | Shift + 2 |
|  | TV |  | Shift + 3 |
|  | CBL - SAT |  | Shift + 4 |
|  | AUX |  | Shift + 5 |
|  | VCR |  | Shift + 6 |
|  | Up / Tune + |  | Up |
|  | Library |  | Text |
|  | Down / Tune - |  | Down |
|  | Left |  | Left |
|  | Right |  | Right |
|  | Enter |  | Ok |
|  | Settings |  | Options |



































Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|------------------|---|---------|
|  | System |  | Menu |
|  | DVD Menu |  | D. Menu |
|  | Guide |  | Guide |
|  | Exit |  | Exit |
|  | Volume + |  | Vol + |
|  | Volume - |  | Vol - |
|  | Track/Chap./CH + |  | Ch + |
|  | Track/Chap./CH - |  | Ch - |
|  | Stop |  | Stop |
|  | Pause |  | Pause |
|  | Play |  | Play |
|  | I<< Seek |  | I<< |
|  | >>I Seek |  | >>I |
|  | Shuffle |  | Smart |
|  | Repeat |  | Media |
|  | 1 |  | 1 |
|  | 2 |  | 2 |





Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|----------|---|--------|
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | Info |  | Info |
|  | Last |  | Pre Ch |
|  | uMusic |  | Dual |
|  | Rating- |  | << |
|  | Rating+ |  | >> |
|  | Encore |  | Red |
|  | CD # |  | Green |
|  | Playlist |  | Yellow |
|  | Whole CD |  | Blue |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|--|--|--|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |








Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|---------------|---|--------------|
|  | On / Off |  | Power |
|  | Mute All |  | Shift + Mute |
|  | Mute |  | Mute |
|  | Stored |  | List |
|  | CD - DVD |  | Shift + 1 |
|  | FM - AM |  | Shift + 2 |
|  | TV |  | Shift + 3 |
|  | CBL - SAT |  | Shift + 4 |
|  | AUX |  | Shift + 5 |
|  | VCR |  | Shift + 6 |
|  | Up / Tune + |  | Up |
|  | Library |  | Text |
|  | Down / Tune - |  | Down |
|  | Left |  | Left |
|  | Right |  | Right |
|  | Enter |  | Ok |
|  | Settings |  | Options |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|------------------|---|---------|
|  | System |  | Menu |
|  | DVD Menu |  | D. Menu |
|  | Guide |  | Guide |
|  | Exit |  | Exit |
|  | Volume + |  | Vol + |
|  | Volume - |  | Vol - |
|  | Track/Chap./CH + |  | Ch + |
|  | Track/Chap./CH - |  | Ch - |
|  | Stop |  | Stop |
|  | Pause |  | Pause |
|  | Play |  | Play |
|  | I<< Seek |  | I<< |
|  | >>I Seek |  | >>I |
|  | Shuffle |  | Smart |
|  | Repeat |  | Media |
|  | 1 |  | 1 |
|  | 2 |  | 2 |





Originalfernbedienung Ersatzfernbedienung

| | | | |
|--|----------|--|--------|
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |
| | Info | | Info |
| | Last | | Pre Ch |
| | uMusic | | Dual |
| | Rating- | | << |
| | Rating+ | | >> |
| | Encore | | Red |
| | CD # | | Green |
| | Playlist | | Yellow |
| | Whole CD | | Blue |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|--|--|--|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

