
















Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	Rec		Rec
	Goto		Smart
	Aspect		3D
	V.Format		Format
	<<		<<
	>>		>>
	Play		Play
	Pause		Pause
	Stop		Stop
	Tv/Radio		TV/R
	Audio		Dual
	Dev		Options
	Recall		Back
	Red/TTX		Red
	Green/SUB.T		Green

Originalfernbedienung Ersatzfernbedienung

	Yellow/Zoom		Yellow
	Blue/Option		Blue
	Info		Info
	FAV		Pre Ch
	Menu		Menu
	Exit		Exit
	Up/CH+		Up
	Down/CH-		Down
	Right/Vol+		Right
	Left/Vol-		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	SAT		Media
	EPG		Guide
	Page+		Ch +
	Page-		Ch -





Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
FIND	Find		
MP	MP		

