









































































Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
			
Power	Power	2	2
			
[i+]	Info	3	3
			
Sleep	Sleep	4	4
			
Media Player	Media	5	5
			
Mute	Mute	6	6
			
▼/O)I/I+II	Dual	7	7
			
Vol+	Vol +	8	8
			
Vol-	Vol -	9	9
			
P+	Ch +	0	0
			
P-	Ch -	OK	Ok
			
Radio	TV/R	Play	Play
			
Source	AV	Pause	Pause
			
Recall	Pre Ch	Menu	Menu
			
[<>]/<	Format	End	Exit
			
PC	D. Menu	Rec	Rec
			
DTV	Smart	Up	Up
			
1	1	>>I	>>I









**Originalfernbedienung Ersatzfernbedienung**

	I<<		I<<
	Down		Down
	Right		Right
	>>		>>
	<<		<<
	Left		Left
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	EPG		Guide
	[≡]		Text
	[≡?]		Options
	[...]		Subt
	FAV/Home		Shift + Pre Ch
	[≡+]/Search		3D
	[≡o]/Widget		Shift + Smart

**Originalfernbedienung Ersatzfernbedienung**

	[≡◆]/Net		Shift + Media
	Rec List		Shift + Info

