
























Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|--------------|---|---------------|
|  | System Power |  | Power |
|  | Sleep |  | Sleep |
|  | Disc Skip |  | Shift + Smart |
|  | CD |  | Yellow |
|  | Play |  | Play |
|  | Pause |  | Pause |
|  | Stop |  | Stop |
|  | I<< |  | I<< |
|  | >>I |  | >>I |
|  | Tape |  | Green |
|  | Shift |  | Menu |
|  | Select 10 |  | Info |
|  | P.File |  | Ch + |
|  | Tuner |  | Blue |
|  | Phono |  | Red |
|  | 1 |  | 1 |
|  | 2 |  | 2 |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|---------|---|---------------|
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 10 |  | 0 |
|  | 11 |  | Guide |
|  | 12 |  | Pre Ch |
|  | 13 |  | AV |
|  | 14 |  | Format |
|  | 15 |  | 3D |
|  | 16 |  | Back |
|  | Video 1 |  | Smart |
|  | Video 2 |  | Media |
|  | Video 3 |  | Shift + Media |





Originalfernbedienung Ersatzfernbedienung

| | | | |
|--|--------------|--|---------------|
| | << Deck A | | << |
| | >> Deck A | | >> |
| | Stop Deck A | | Stop |
| | < Deck A | | Left |
| | Deck A > | | Right |
| | System Power | | Power |
| | Vol+ | | Vol + |
| | Vol- | | Vol - |
| | Pause Deck A | | Pause |
| | O Deck A | | Play |
| | Rec Deck A | | Rec |
| | << Deck B | | l<< |
| | >> Deck B | | >>l |
| | < Deck B | | SHIFT + Left |
| | Deck B > | | SHIFT + Right |
| | Stop Deck B | | SHIFT + Stop |
| | Pause Deck B | | SHIFT + Pause |

Originalfernbedienung Ersatzfernbedienung

| | | | |
|--|------------|--|---------------|
| | O Deck B | | Text |
| | Rec Deck B | | AV |
| | CD | | Yellow |
| | Tape | | Green |
| | Tuner | | Blue |
| | Phono | | Red |
| | Video 1 | | Smart |
| | Video 2 | | Media |
| | Video 3 | | Shift + Media |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |



