





































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	16:9 Wide		Format
	Red		Red
	Green / Subtitle		Green
	Green / Subtitle		Subt
	Yellow / FAV		Yellow
	Yellow / FAV		Shift + Pre Ch
	Blue / EPG		Blue
	Blue / EPG		Shift + Guide
	I<< / Hold		I<<
	>>I / List		List
	>>I / List		>>I
	<< / Language		Dual
	<< / Language		<<
	>> / Radio		>>
	>> / Radio		TV/R
	Play / Index		Play


































Originalfernbedienung Ersatzfernbedienung

	Pause / Zoom		Pause
	Pause / Zoom		Eject
	Stop / Reveal		Stop
	Back / TTX		Back
	Back / TTX		Text
	Info		Info
	Rec		Rec
	L / R		Shift + Dual
	Smart S		Smart
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	OK		Ok
	Source		AV
	Menu		Menu
	Vol +		Vol +





Originalfernbedienung Ersatzfernbedienung

	Vol -		Vol -
	F1		Media
	Mute		Mute
	CH +		Ch +
	CH -		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Pre Ch
	Guide		Guide

Originalfernbedienung Ersatzfernbedienung

