






Originalfernbedienung Ersatzfernbedienung

|                                                                                     |          |                                                                                     |                             |
|-------------------------------------------------------------------------------------|----------|-------------------------------------------------------------------------------------|-----------------------------|
|    | Power    |    | Power                       |
|    | Red/↑    |    | Red / Netflix / Search      |
|    | Green/↓  |    | Green / APP / Repeat        |
|    | Yellow   |    | Yellow / YouTube / Repeat   |
|    | Blue     |    | Blue / Prime Video / Random |
|    | [≡]      |    | Text / Goto                 |
|    | [≡x]     |    | Exit / Cancel / Clear       |
|    | EPG      |    | Guide / EPG / -/--          |
|    | [*]/[■]  |    | Zoom / Size                 |
|   | Screen   |   | Picture / Format            |
|  | Lang     |  | Audio / Lang I/II           |
|  | Subtitle |  | Subtitle / EQ               |
|  | Sleep    |  | Sleep / Timer               |
|  | 1        |  | 1                           |
|  | 2        |  | 2                           |
|  | 3        |  | 3                           |
|  | 4        |  | 4                           |













Originalfernbedienung Ersatzfernbedienung

|                                                                                       |             |                                                                                       |                   |
|---------------------------------------------------------------------------------------|-------------|---------------------------------------------------------------------------------------|-------------------|
|    | 5           |    | 5                 |
|    | 6           |    | 6                 |
|    | 7           |    | 7                 |
|    | 8           |    | 8                 |
|    | 9           |    | 9                 |
|    | FAV         |    | Fav / Marker / PC |
|    | 0           |    | 0                 |
|    | Tv/DTV      |    | TV/Radio /        |
|    | Vol-        |    | Vol-              |
|   | Vol+        |   | Vol+              |
|  | Mute        |  | Mute / Dimmer     |
|  | PR-         |  | CH- / Page-       |
|  | PR+         |  | CH+ / Page+       |
|  | Preset      |  | Smart / List      |
|  | Source      |  | AV / Input / RDS  |
|  | Info/[≡?]   |  | Info / Angle      |
|  | Swap/Recall |  | Display / Media   |





Originalfernbedienung    Ersatzfernbedienung

|                                                                                   |        |                                                                                   |               |
|-----------------------------------------------------------------------------------|--------|-----------------------------------------------------------------------------------|---------------|
|  | Return |  | Back / Return |
|  | Up     |  | Up            |
|  | Left   |  | Left          |
|  | OK     |  | OK            |
|  | Right  |  | Right         |
|  | Down   |  | Down          |
|  | M      |  | Menu / Home   |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |
|                                                                                   |        |                                                                                   |               |

Originalfernbedienung    Ersatzfernbedienung

|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |

