

ENGEL
TV
RS4800Y (REV.2015)

Mandis Shop S.L.
Sant Cugat del Vallès - Barcelona
info@mandis.es

Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
	POWER		P/Ch + 	P+	SKIP NEXT CHAP
MUTE	MUTE		P/Ch - 	P-	SKIP PREV CHAP
1 	1		VOL + 	VOL+	
2 	2		VOL - 	VOL-	
3 	3			UP	
4 	4			DOWN	
5 	5		OK		
6 	6			LEFT	
7 	7			RIGHT	
8 	8		MENU	MENU	
9 	9		EXIT RETURN	EXIT	
0/10 	0		 TOP MENU	HOME	
1.  GUIDE	MEDIA	GUIDE	PICT TITLE		
2.  FAV		FAV	 EPG	GUIDE	
 AUTO/TRK			 		
 SUBT	SUBTITLE		 		STOP
AV Dvd/Tv	AUDIO		 ZOOM	FORMAT	
 INFO	INFO				PAUSE
TEXT	TXT		RED 	RED	REC
TV			GREEN 	GREEN	
 BACK	BACK		YELLOW 	YELLOW	PLAY
			BLUE 	BLUE	FWD