
















































Original	Replacement
	
Power	Power
	
Source	AV
	
1	1
	
2	2
	
3	3
	
4	4
	
5	5
	
6	6
	
7	7
	
8	8
	
9	9
	
0	0
	
Recall	Pre Ch
	
TV	TV/R
	
Menu	Menu
	
Q.Menu	D. Menu
	
World	Shift + Guide

Original	Replacement
	
OK	Ok
	
Up	Up
	
Down	Down
	
Right	Right
	
Left	Left
	
PR+	Ch +
	
PR-	Ch -
	
Vol+	Vol +
	
Vol-	Vol -
	
Exit	Exit
	
Back	Back
	
Mute	Mute
	
i	Info
	
Guide	Guide
	
[≡]/Text	Text
	
Folder	Format
	
[-O-]	Subt





Original		Replacement		Original	Replacement
	*/O		Sleep		
	*/Q		Eject		
	Netflix		Media		
	Camera-Music-Ph		Options		
	YouTube		3D		
	[≡]..		List		
	Lang		Dual		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	Play		Play		
	Rec		Rec		
	Pause		Pause		
	>>		>>		
	<<		<<		
	Stop		Stop		

