















































































































Original	Replacement	Original	Replacement
	Power		Power
	Source		AV
	TV		TV/R
	3D		3D
	[<>]		Format
	O)/II		Dual
	Subtitle		Subt
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AD		Shift + Subt
	Recall		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	[i+]		Info
	Quick		Smart
	P+		Ch +
	P-		Ch -
	[■]		Options
	[>]		Media
	Text		Text
	List		List
	↑		Shift + Up
	↓		Shift + Down
	→		Shift + Right
	←		Shift + Left





Original		Replacement		Original		Replacement	
	Menu		Menu		Green		Green
	Guide		Guide		Yellow		Yellow
	Back		Back		Blue		Blue
	Exit		Exit				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	OK		Ok				
	<</[≡+]		<<				
	Play		Play				
	>>/[≡◇]		>>				
	I<</[≡?]		I<<				
	Stop		Stop				
	/ >/[▼]		Pause				
	>>I/[O]/[≡x]		>>I				
	Red		Red				

