







































































| Original  | Replacement | Original  | Replacement           |
|---|-------------|---|-----------------------|
|      | Power       |      | Power                 |
|      | Source      |      | AV / Input / RDS      |
|      | 1           |      | 1                     |
|      | 2           |      | 2                     |
|      | 3           |      | 3                     |
|      | 4           |      | 4                     |
|      | 5           |      | 5                     |
|      | 6           |      | 6                     |
|      | 7           |      | 7                     |
|      | 8           |      | 8                     |
|    | 9           |    | 9                     |
|    | 0           |    | 0                     |
|    | [TV]        |    | TV/Radio /            |
|    | Internet    |    | Smart / List          |
|    | ↔           |    | Fav / Marker / PC     |
|    | Mute        |    | Mute / Dimmer         |
|    | Vol+        |    | Vol+                  |
|    | Vol-        |    | Vol-                  |
|    | P+          |    | CH+ / Page+           |
|    | P-          |    | CH- / Page-           |
|    | OK          |    | OK                    |
|    | Menu        |    | Menu / Home           |
|    | Back        |    | Back / Return         |
|    | Exit        |    | Exit / Cancel / Clear |
|    | Q.Menu      |    | D.Menu / Top          |
|    | Up          |    | Up                    |
|    | Down        |    | Down                  |
|  | Right       |  | Right                 |
|  | Left        |  | Left                  |
|  | i           |  | Info / Angle          |
|  | EPG         |  | Guide / EPG / -/-     |
|  | TXT         |  | Text / Goto           |
|  | Lang.       |  | Audio / Lang I/II     |
|  | Subt.       |  | Subtitle / EQ         |





| Original  | Replacement | Original  | Replacement                 |
|---|-------------|---|-----------------------------|
|    | Red         |    | Red / Netflix / Search      |
|    | [>]         |    | Picture / Format            |
|    | [+]         |    | Zoom / Size                 |
|    | Green       |    | Green / APP / Repeat        |
|    | Yellow      |    | Yellow / YouTube / Repeat   |
|    | *1/O        |    | Shift + 1                   |
|    | *2/Q        |    | Shift + 2                   |
|    | Blue        |    | Blue / Prime Video / Random |
|    | Rec         |    | Rec / Rec Mode              |
|    | Play        |    | Play / Slow                 |
|   | Pause       |   | Pause / Step / Freeze       |
|  | >>          |  | >> / Tune+                  |
|  | <<          |  | << / Tune-                  |
|  | Stop        |  | Stop / Hold                 |
|   |             |   |                             |
|   |             |   |                             |
|   |             |   |                             |

