


































































































Original	Replacement	Original	Replacement
 Power	 Power	 Exit	 Exit
 [=i]/Info	 Info	 ♪	 Shift + Dual
 Mute	 Mute	 Enter	 Ok
 1	 1	 Up	 Up
 2	 2	 Down	 Down
 3	 3	 Right	 Right
 4	 4	 Left	 Left
 5	 5	 CH+	 Ch +
 6	 6	 CH-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 [=♦]/[+]	 Format
 0	 0	 List	 List
 [=?]/Source	 AV	 EPG	 Guide
 O)/II/Audio	 Dual	 Recall	 Pre Ch
 *	 Options	 [=]	 Text
 Menu	 Menu	 Play	 Play





Original		Replacement		Original		Replacement	
	Pause		Pause				
	[≡+]/Still		3D				
	Stop		Stop				
	[≡o]/Subtitle		Subt				
	Radio		TV/R				
	Sleep		Sleep				
	FAV-		Shift + Ch -				
	FAV+		Shift + Ch +				
	Red		Red				
	<<		<<				
	Green		Green				
	>>		>>				
	l<<		l<<				
	Yellow		Yellow				
	Blue		Blue				
	>>l		>>l				
	[≡x]/Repeat		D. Menu				

