Original		Replacement		Original	Replacement
	Power		Power		
SOURCE	Source	TIMER AV	AV		
	Vol +	+ VOL	Vol +		
	Vol -	VOL −	Vol -		
	Mute	MUTE	Mute		
	Back	RETURN BACK	Back		
	Play/Pause	PLAY MODE ▶	Play		
	>>|	>>|	>>|		
	|<<	|<<	|<<		
SOUND	Sound	SOUND DUAL	Dual		
SOUND EFFECT	Sound Effect	SETTINGS OPT	Options		
SOUND CONTROL	Sound Control	AD SUBT	Subt		
Bluetooth POWER	Bluetooth	REPEAT TEXT	Text		
WOOFER	Woofer	HOME SMART	Smart		
AUTO POWER	Auto Power	PICTURE FORMAT	Format		