

































































| Original  |                      | Replacement   |                             | Original  |          | Replacement   |                       |
|---|----------------------|---|-----------------------------|---|----------|---|-----------------------|
|    | Power                |    | Power                       |    | Pause    |    | Pause / Step / Freeze |
|    | Red                  |    | Red / Netflix / Search      |    | I<       |    | I<< / Preset-         |
|    | Green                |    | Green / APP / Repeat        |    | Stop     |    | Stop / Hold           |
|    | Yellow               |    | Yellow / YouTube / Repeat   |    | Eject    |    | Eject / Surround      |
|    | Blue                 |    | Blue / Prime Video / Random |    | >I       |    | >>I / Preset+         |
|    | PopUp Menu/Disc Menu |    | D.Menu / Top                |    | <<       |    | << / Tune-            |
|    | Home                 |    | Menu / Home                 |    | >>       |    | >> / Tune+            |
|    | Top Menu             |    | Picture / Format            |    | 1        |    | 1                     |
|    | Up                   |    | Up                          |    | 2        |    | 2                     |
|  | Left                 |  | Left                        |  | 3        |  | 3                     |
|  | OK                   |  | OK                          |  | 4        |  | 4                     |
|  | Right                |  | Right                       |  | 5        |  | 5                     |
|  | Down                 |  | Down                        |  | 6        |  | 6                     |
|  | Back                 |  | Back / Return               |  | 7        |  | 7                     |
|  | :≡                   |  | Smart / List                |  | 8        |  | 8                     |
|  | :≡                   |  | Setup / OPT /               |  | 9        |  | 9                     |
|  | Play                 |  | Play / Slow                 |  | Subtitle |  | Subtitle / EQ         |



