









Original	Replacement	Original	Replacement
 Power	 Power	 Yellow	 Yellow
 Play	 Play	 Index	 List
 Pause	 Pause	 Blue	 Blue
 <<	 <<	 CH+	 Ch +
 >>	 >>	 CH-	 Ch -
 I<<	 I<<	 Input	 AV
 >>I	 >>I	 Vol+	 Vol +
 Stop	 Stop	 Vol-	 Vol -
 Rec	 Rec	 Mute	 Mute
 Tv/TXT	 Text	 Menu	 Menu
 Cancel	 Shift + Exit	 Exit	 Exit
 Hold	 Options	 DVB	 Smart
 Reveal	 D. Menu	 Up	 Up
 Size	 3D	 Down	 Down
 Red	 Red	 Right	 Right
 Green	 Green	 Left	 Left
 Subpage	 Eject	 OK	 Ok





Original	Replacement
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
	+  Shift + Guide
	Back
	+  Shift + Format
	+  Shift + Dual
	Media
	Sleep
	TV/R

Original	Replacement
	FAV
	FAV+
	FAV-
	Subtitle
	Pic Format
	Language
	Text
	EPG
	Display
	Pre Ch
+	Shift + Ch +
+	Shift + Ch -
	Subt
	Format
	Dual
+	Shift + Text
	Guide
	Info

