





































































Original	Replacement
 Power	 Power
 12/24H	 Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Pause	 Pause
 Restart	 Back
 Exit	 Exit
 Select	 Menu
 Up	 Up

Original	Replacement
 Dn	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 F1	 List
 F2	 Dual
 F3	 Subt
 F4	 Options
 F5	 Sleep
 F6	 TV/R
 F7	 Format
 F8	 3D
 F9	 Red
 F10	 Green
 F11	 Yellow
 F12	 Blue

