

































	Original	Replacement		Original	Replacement
	Power		Power		
	Mute		Mute		
	Menu		Menu		
	CH+		Ch +		
	CH-		Ch -		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	OK		Ok		
	Vol+		Vol +		
	Vol-		Vol -		
	Z		Info		
	TV-G		Guide		
	AV		AV		

