







































































| Original | | Replacement | | Original | | Replacement | |
|---|----------|---|-------------------|---|--------|---|-----------------------|
|  | TV/PC |  | Eject / Surround |  | 0 |  | 0 |
|  | Power |  | Power |  | Q.View |  | Display / Media |
|  | Input |  | AV / Input / RDS |  | Menu |  | Menu / Home |
|  | TV/Radio |  | TV/Radio / |  | Up |  | Up |
|  | Text |  | Text / Goto |  | Exit |  | Exit / Cancel / Clear |
|  | I-II |  | Audio / Lang I/II |  | Left |  | Left |
|  | Mute |  | Mute / Dimmer |  | OK |  | OK |
|  | 1 |  | 1 |  | Right |  | Right |
|  | 2 |  | 2 |  | Info |  | Info / Angle |
|  | 3 |  | 3 |  | Down |  | Down |
|  | 4 |  | 4 |  | Guide |  | Guide / EPG / -/- |
|  | 5 |  | 5 |  | Vol+ |  | Vol+ |
|  | 6 |  | 6 |  | Return |  | Back / Return |
|  | 7 |  | 7 |  | PR+ |  | CH+ / Page+ |
|  | 8 |  | 8 |  | Vol- |  | Vol- |
|  | 9 |  | 9 |  | PR- |  | CH- / Page- |
|  | List |  | Smart / List |  | FAV |  | Fav / Marker / PC |





| Original | Replacement | Original | Replacement |
|---|-----------------------------|----------|-------------|
|  | Red / Netflix / Search | | |
|  | Green / APP / Repeat | | |
|  | Stop / Hold | | |
|  | Yellow / YouTube / Repeat | | |
|  | Play / Slow | | |
|  | Blue / Prime Video / Random | | |
|  | Pause / Step / Freeze | | |
|  | D.Menu / Top | | |
|  | << / Tune- | | |
|  | Setup / OPT / | | |
|  | >> / Tune+ | | |
|  | Subtitle / EQ | | |
|  | Picture / Format | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

