Original	Replacement	Original	Replacement
Standby Tv	Power	☼	Options
Mute	Mute	OK	Ok
1	1	Up	Up
2	2	Down	Down
3	3	Right	Right
4	4	Left	Left
5	5	Vol +	Vol +
6	6	Vol -	Vol -
7	7	Menu	Menu
8	8	Prog+	Ch +
9	9	Prog-	Ch -
0	0	Red	Red
[i+]/[?]	Info	Green	Green
Recall/-/--	Pre Ch	Yellow	Yellow
[≡]	Text	Blue	Blue
[I]	Guide	Stop	Stop
♪	Dual	<<	<<

Original	Replacement	Original	Replacement
Play	Play		
>>	>>		
[+]	3D		
Source	AV		
[II]	Subt		
[ ]	TV/R		
[<>]	Format		