



Original	Replacement	Original	Replacement
 Power	 Power	 Ratio/Char/Num	 Dual
 Energy/Saving	 3D	 Q.View	 D. Menu
 AV Mode	 Shift + AV	 Vol+	 Vol +
 Input	 AV	 Vol-	 Vol -
 Tv/Radio	 TV/R	 Mute/Delete	 Mute
 1	 1	 P+	 Ch +
 2	 2	 P-	 Ch -
 3	 3	 Premium	 Media
 4	 4	 Home Netcast	 Smart
 5	 5	 Q.Menu	 Menu
 6	 6	 Back	 Back
 7	 7	 Guide	 Guide
 8	 8	 Exit	 Exit
 9	 9	 Up	 Up
 0	 0	 Down	 Down
 List	 List	 Right	 Right
 FAV/Mark	 Pre Ch	 Left	 Left





Original	Replacement	Original	Replacement
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text		Text
	Subtitle		Subt
	T.Opt		Options
	Simplink		Format
	Info		Info
	AD		Shift + Subt
	Stop		Stop
	Play		Play
	Pause		Pause
	<<		<<
	>>		>>

