



Original	Replacement	Original	Replacement
 Power	 Power	 Hold/EPG	 Guide
 Mute	 Mute	 Red	 Red
 1	 1	 Green	 Green
 2	 2	 Yellow	 Yellow
 3	 3	 Blue	 Blue
 4	 4	 Vol+	 Vol +
 5	 5	 Vol-	 Vol -
 6	 6	 I-II	 Dual
 7	 7	 Source	 AV
 8	 8	 Freeze	 Options
 9	 9	 CH+	 Ch +
 0	 0	 CH-	 Ch -
 Back/S.Page	 Back	 Sleep	 Sleep
 Text	 Text	 Menu	 Menu
 Index/PVR List	 Smart	 DTV/Radio	 TV/R
 Rec/Reveal	 Rec	 Exit	 Exit
 Zoom/T.Shift	 Eject	 Aspect	 3D





Original	Replacement	Original	Replacement
 P.Mode	 Format	 FAV	 Pre Ch
 S.Mode	 Shift + Dual	 FAV+/Repeat	 Shift + Ch +
 Up	 Up	 FAV-/A-B	 Shift + Ch -
 Down	 Down		
 Right	 Right		
 Left	 Left		
 OK	 Ok		
 Media	 Media		
 Info/Slow	 Info		
 Step/Subtitle	 Subt		
 Play	 Play		
 Pause	 Pause		
 I<<	 I<<		
 >>I	 >>I		
 Stop	 Stop		
 <<	 <<		
 >>	 >>		

