
































Original		Replacement		Original		Replacement	
	Power		Power		Recall		Back
	Mute		Mute		Text		Text
	Red		Red		Subtitle		Subt
	Blue/Pause		Blue		USB		AV
	Green		Green		Menu		Menu
	Yellow		Yellow		Exit		Exit
	Audio		Dual		EPG		Guide
	Zoom		Eject		FAV		Pre Ch
	Info		Info		Up		Up
	<<		<<		Down		Down
	>>		>>		Right		Right
	l<<		l<<		Left		Left
	>>l		>>l		OK		Ok
	Play		Play		Find		Options
	Stop		Stop		SAT		Format
	Rec		Rec		HDMI		Smart
	Pause		Pause		F1		Media





Original	Replacement	Original	Replacement
 Page+	 Ch +		
 Page-	 Ch -		
 1	 1		
 2	 2		
 3	 3		
 4	 4		
 5	 5		
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 Sleep	 Sleep		
 TV/Radio	 TV/R		

