














































































Original	Replacement	Original	Replacement
 Power	 Power	 0	 0
 Mute	 Mute / Dimmer	 Info	 Info / Angle
 Rec	 Rec / Rec Mode	 <<	 << / Tune-
 TV Sys.	 D.Menu / Top	 Vol -	 Vol-
 Browser	 Display / Media	 Vol +	 Vol+
 Copy	 Picture / Format	 I<<	 I<< / Preset-
 Music	 Smart / List	 >>	 >> / Tune+
 1	 1	 Play / Pause	 Play / Slow
 2	 2	 Play / Pause	 Pause / Step / Freeze
 3	 3	 Stop	 Stop / Hold
 4	 4	 >>I	 >>I / Preset+
 5	 5	 Home	 Shift + Menu /
 6	 6	 Up	 Up
 7	 7	 Return	 Back / Return
 8	 8	 Left	 Left
 9	 9	 Enter	 OK
 Repeat	 Shift + Green / APP / Repeat	 Right	 Right





Original	Replacement	Original	Replacement
 Menu	 Menu / Home		
 Down	 Down		
 Setup	 Setup / OPT /		
 Time Shift	 Sleep / Timer		
 Slow I>	 Shift + Play /		
 A-B	 Shift + YouTube /		
 Goto	 Shift + Text /		
 Zoom	 Zoom / Size		
 Audio	 Audio / Lang I/II		
 Subtitle	 Subtitle / EQ		
 Angle	 Shift + Info / Angle		
 Red	 Red / Netflix / Search		
 Green / EPG	 Green / APP / Repeat		
 Green / EPG	 Guide / EPG / -/--		
 Yellow / Text	 Text / Goto		
 Yellow / Text	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		

Original	Replacement	Original	Replacement

