












































































Original		Replacement		Original		Replacement	
	Power		Power		EPG		Guide
	Info		Info		Recall		Back
	Mute		Mute		Freeze		Pause
	P.Mode		Shift + Format		Sleep		Sleep
	S.Mode		Dual		Menu		Menu
	Nicam		Shift + Dual		Source		AV
	Aspect		Format		Up		Up
	1		1		Right		Right
	2		2		Down		Down
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Vol -		Vol -
	6		6		Vol +		Vol +
	7		7		CH -		Ch -
	8		8		CH +		Ch +
	9		9		Txt / Repeat		Text
	0		0		Hold / A-B		Shift + Pause





Original	Replacement
 Mix / Language	 Shift + Text
 Subtitle /	 Subt
 Index / Setup	 Options
 Size / DVD	 D. Menu
 Reveal / Title	 Smart
 Cancel / Exit / Zoom	 Exit
 Red / Program	 Red
 Green / Goto	 Green
 Yellow / Angle	 Yellow
 Blue / D.Dis	 Blue
 Play / Pause	 Play
 List / Stop	 Stop
 List / Stop	 List
 DTV/Radio / <<<	 TV/R
 DTV/Radio / <<<	 <<<
 Fav / >>>	 Pre Ch
 Fav / >>>	 >>>

Original	Replacement
 Rec / Open/Close	 Rec
 T-Shift	 3D
 Page Up / I<<<	 I<<<
 Page Down / >>>I	 >>>I

