

















































Original		Replacement		Original		Replacement	
	Power		Power		Source		AV
	Audio I/II		Dual		Info		Info
	Mute		Mute		Up		Up
	1		1		Right		Right
	2		2		Down		Down
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Vol +		Vol +
	6		6		Vol -		Vol -
	7		7		CH +		Ch +
	8		8		CH -		Ch -
	9		9		Red		Red
	0		0		Green		Green
	Sleep		Sleep		Yellow		Yellow
	Recall		Back		Blue		Blue
	Exit		Exit		P.Mode		Format
	Menu		Menu		S.Mode		Shift + Dual





	Original	Replacement	Original	Replacement
	P.Size			Eject
	Subtitle			Subt
	Play/Pause / TS			Play
	Play/Pause / TS			Pause
	Stop			Stop
	Rec			Rec
	Text			Text
	<< / PVR List			<<
	<< / PVR List			List
	>> / DTV/Radio			>>
	>> / DTV/Radio			TV/R
	I<< / Fav.CH			I<<
	I<< / Fav.CH			Pre Ch
	>>I / Guide			>>I
	>>I / Guide			Guide

