







































































Original	Replacement	Original	Replacement
 PowerTv	 Power	 ← Time Shift	 I<< / Preset-
 NET	 Shift + Fav / Marker / PC	 Pause Time Shift	 Pause / Step / Freeze
 [i+]	 Info / Angle	 → Time Shift	 >>I / Preset+
 P.Info	 Shift + Info / Angle	 1	 1
 ATV	 Shift + 1	 2	 2
 DTV	 Shift + 2	 3	 3
 SAT	 Shift + 0	 4	 4
 Radio	 TV/Radio /	 5	 5
 Power Source	 Shift + Power	 6	 6
 << Source	 << / Tune-	 7	 7
 Play Source	 Play / Slow	 8	 8
 >> Source	 >> / Tune+	 9	 9
 Control	 Smart / List	 Recall	 Fav / Marker / PC
 Rec Source	 Rec / Rec Mode	 0	 0
 Rec Stop	 Shift + Stop /	 Source	 AV / Input / RDS
 Stop Source	 Stop / Hold	 I/II/I+II/▼/O	 Audio / Lang I/II
 Ready Time Shift	 Sound / Title	 [<>]	 Picture / Format





Original	Replacement	Original	Replacement
AV Mode	Setup / OPT /	Back	Back / Return
Eco	D.Menu / Top	[...]	Subtitle / EQ
Mute	Mute / Dimmer	[≡?]	Eject / Surround
Vol+	Vol+	[≡o]	Sleep / Timer
P+	CH+ / Page+	[≡+]	Display / Media
[≡]	Text / Goto	Red	Red / Netflix / Search
Vol-	Vol-	Green	Green / APP / Repeat
P-	CH- / Page-	Yellow	Yellow / YouTube / Repeat
3D	Zoom / Size	Blue	Blue / Prime Video / Random
Menu	Menu / Home		
EPG	Guide / EPG / -/--		
Up	Up		
Left	Left		
OK	OK		
Right	Right		
End	Exit / Cancel / Clear		
Down	Down		

