

































Original	Replacement
 Power	 Power
 TV/R	 TV/R
 APP	 Media
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info
 PiP	 Smart
 Vol+	 Vol +

Original	Replacement
 Vol-	 Vol -
 Back	 Back
 Exit	 Exit
 CH+	 Ch +
 CH-	 Ch -
 EPG	 Guide
 Menu	 Menu
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Rec	 Rec
 PVR	 Options
 Play / Pause	 Play
 Play / Pause	 Pause
 Stop	 Stop





Original	Replacement
	<<
	>>
	3D
	List
	Dual
	Pre Ch
	Sleep
	Shift + Ch +
	Subt
	>>
	Text
	Shift + Ch -
	Eject
	I<<
	Red
	Green
	Yellow

Original	Replacement
	Blue

