















































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	More		Smart
	Code		Media
	Code		Shift + Media
	Sleep		Sleep
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Zoom		Eject
	OPT		Options
	Red / <<		Red
	Green / Stop		Green
	Yellow /		Yellow
	Blue / >>		Blue
	Red / <<		<<
	Green / Stop		Stop
	Yellow /		Play
	Yellow /		Pause
	Blue / <<		>>
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	TV/Radio		TV/R
	Rec		Rec









































Original		Replacement		Original		Replacement	
	Back		Back				
	Info		Info				
	Prog-		Ch -				
	Prog+		Ch +				
	Vol-		Vol -				
	Vol+		Vol +				
	TXT		Text				
	Still	 + 	Shift + Pause				
	Sound		Dual				
	PIP		Format				
	Menu		Menu				
	HDMI		AV				









Original	Replacement	Original	Replacement
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Opt?	 Options	Menu Down	 Down
Subt.List	 Subt	Back	 Back
App	 Media	Audio	 Dual
Info	 +  Shift + Info	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7









































Original	Replacement	Original	Replacement
8tuv	 8	Lang./Rewind	 <<
9wxyz	 9	LNB F.Forward	 >>
Guide Pilote	 Guide		
0/10	 0		
FAV Pref.	 Pre Ch		
Red	 Red		
Green	 Green		
Dev	 List		
Home Cinema	 Smart		
West	 I<<		
Yellow	 Yellow		
Freeze	 Stop		
Blue	 Blue		
On/Off	 +  Shift + Power		
SAT Sky	 +  Shift + AV		
H/V Play	 Play		
East	 >>I		























































Original	Replacement	
PWR On/Off		Power
Mute		Mute
Epg	 + 	Shift + Guide
Sleep Timer		Sleep
Opt?		Options
App		Media
Info	 + 	Shift + Info
TV		TV/R
Video		D. Menu
Text		Text
Zoom		Eject
TV/SAT		AV
Menu		Menu
Menu Up		Up
Display		Info
Menu Left		Left
OK Enter		Ok

Original	Replacement	
Menu Right		Right
Exit		Exit
Menu Down		Down
Back		Back
Audio		Dual
Volume+		Vol +
CH/Page+		Ch +
Volume-		Vol -
CH/Page-		Ch -
1. ?		1
2abc		2
3def		3
4ghi		4
5jkl		5
6mno		6
7pqrm		7
8tuv		8





Original	Replacement	Original	Replacement
9wxyz	 9	East	 >>
Guide Pilote	 Guide	Lang./Rewind	 <<
0/10	 0	H/V Play	 Play
FAV Pref.	 Pre Ch	LNB F.Forward	 >>
Freeze	 Stop		
Scan/Setup	 +  Shift + Options		
Red	 Red		
Auth./DISEQC	 List		
Green	 Green		
Radio	 +  Shift + TV/R		
Yellow	 Yellow		
Blue	 Blue		
Home Cinema	 Smart		
Alt/16:9	 Format		
SAT Sky	 +  Shift + AV		
Dec/Pause	 Pause		
	 +  Shift + Exit		

Original	Replacement	Original	Replacement
9wxyz	 9	East	 >>
Guide Pilote	 Guide	Lang./Rewind	 <<
0/10	 0	H/V Play	 Play
FAV Pref.	 Pre Ch	LNB F.Forward	 >>
Freeze	 Stop		
Scan/Setup	 +  Shift + Options		
Red	 Red		
Auth./DISEQC	 List		
Green	 Green		
Radio	 +  Shift + TV/R		
Yellow	 Yellow		
Blue	 Blue		
Home Cinema	 Smart		
Alt/16:9	 Format		
SAT Sky	 +  Shift + AV		
Dec/Pause	 Pause		
	 +  Shift + Exit		

