







































































Original	Replacement	Original	Replacement
 Power	 Power	 Down / PR-	 Ch -
 Info	 Info	 Right / Vol+	 Right
 Mute	 Mute	 Right / Vol+	 Vol +
 Picture	 Format	 Left / Vol-	 Left
 V.Size	 3D	 Left / Vol-	 Vol -
 Source	 AV	 Menu	 Menu
 Sound	 Dual	 Menu	 Ok
 S.Mode	 Shift + Dual	 1	 1
 Still	 Pause	 2	 2
 Digest	 Smart	 3	 3
 Pre.PR	 Back	 4	 4
 Sleep	 Sleep	 5	 5
 Text	 Text	 6	 6
 Exit	 Exit	 7	 7
 Up / PR+	 Up	 8	 8
 Up / PR+	 Ch +	 9	 9
 Down / PR-	 Down	 0	 0



