























































Original	Replacement	Original	Replacement
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Info	 +  Shift + Info	Menu Down	 Down
App	 Media	Back	 Back
Opt?	 Options	Audio	 Dual
Subt.List	 Subt	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7



Original	Replacement	
8tuv	 8	8
9wxyz	 9	9
Guide Pilote	 GUIDE	Guide
0/10	 0	0
FAV Pref.	 PRE-CH	Pre Ch
Red	 A	Red
Green	 B	Green
Yellow	 C	Yellow
Blue	 D	Blue
Dev	 LIST	List
On/Off	 + 	Shift + Power
	 + 	Shift + Mute
West	 + 	Shift + I<<
+	 + 	Shift + Subt
Freeze		Stop
Dec/Pause		Pause
Sys/Serv	 + 	Shift + Sleep

Original	Replacement	
Scan/Setup	 + 	Shift + TV/R
SAT Sky	 Smart	Smart
	 + 	Shift + Vol +
		>>I
	 + 	Shift + Vol -
Home Cinema	 + 	Shift + Media
East	 + 	Shift + Red
		I<<
Lang./Rewind		<<
H/V Play		Play
LNB F.Forward		>>

