







































































Original	Replacement	Original	Replacement
 Power	 Power	 P+	 Ch +
 1	 1	 P-	 Ch -
 2	 2	 Home	 Shift + Smart
 3	 3	 Guide	 Guide
 4	 4	 i	 Info
 5	 5	 EXIT	 Exit
 6	 6	 ←	 Back
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Right	 Right
 0	 0	 Left	 Left
 Lang	 Dual	 OK	 Ok
 [=]..	 Subt	 Netflix	 Media
 V+	 Vol +	 YouTube	 List
 V-	 Vol -	 prime video	 Options
 Mute	 Mute	 Google Play	 TV/R
 Smart	 Smart	 Menu	 Menu





Original		Replacement		Original		Replacement	
	Source		AV				
	<<		<<				
	Stop		Stop				
	>>		>>				
	Rec		Rec				
	Pause		Pause				
	Play		Play				
	Text		Text				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

