

























































































Original	Replacement	Original	Replacement
 Power	 Power	 9	 9
 Red	 Red / Netflix / Search	 0/AV	 0
 Green	 Green / APP / Repeat	 P+	 CH+ / Page+
 Yellow	 Yellow / YouTube / Repeat	 P-	 CH- / Page-
 Blue	 Blue / Prime Video / Random	 Vol+	 Vol+
 [=+]	 Setup / OPT /	 Vol-	 Vol-
 [/ =]	 AV / Input / RDS	 N/E	 OK
 [= x]	 Picture / Format	 Right	 Right
 [=]	 Text / Goto	 Left	 Left
 1	 1	 Up	 Up
 2	 2	 Down	 Down
 3	 3	 P/C	 Back / Return
 4	 4	 i	 Info / Angle
 5	 5	 Mute	 Mute / Dimmer
 6	 6	 Color-	 << / Tune-
 7	 7	 Color+	 >> / Tune+
 8	 8	 Brightness-	 I<< / Preset-







Original	Replacement
	Power
	Red
	Green
	Yellow
	Blue
	0/AV
	Vol+
	Vol-
	P+
	P-
	Down
	Up
	N/E
	Right
	Left
	i
	Mute

Original	Replacement
	Rec
	Stop
	Pause
	Play
	Tint-
	Tint+
	<<
	>>
	I>
	I<<
	>>I

