











































































Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Recall		Back / Return
	0		0
	SAT		Shift + 0
	SAT		AV / Input / RDS
	TV/Radio		TV/Radio /
	Audio		Audio / Lang I/II
	Subtitle		Subtitle / EQ
	Text		Text / Goto
	Live		Display / Media
	VOD		Smart / List
	Series		Shift + Display / Media
	WEB TV		Shift + Smart / List
	Menu		Menu / Home
	Up		Up
	Exit		Exit / Cancel / Clear
	Left		Left
	OK		OK
	Right		Right
	EPG		Guide / EPG / -/--
	Down		Down
	Info		Info / Angle
	Vol+		Vol+
	Fav		Fav / Marker / PC
	Page+		CH+ / Page+





Original	Replacement
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Page-	 CH- / Page-
 Red / F1	 Red / Netflix / Search
 Green / F2	 Green / APP / Repeat
 Yellow / F3	 Yellow / YouTube / Repeat
 Blue / IPTV	 Blue / Prime Video / Random
 Option	 Setup / OPT /
 V-Format	 Picture / Format
 Resolution	 Zoom / Size
 Sleep	 Sleep / Timer
 <<	 << / Tune-
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze

Original	Replacement
 Stop	 Stop / Hold
 Rec	 Rec / Rec Mode

