
































































| Original | Replacement | Original | Replacement |
|---|--|--|---|
|  Power |  Power |  9 |  9 |
|  TV |  Smart / List |  Sol- |  << / Tune- |
|  Text |  Text / Goto |  Sol+ |  >> / Tune+ |
|  Source 2 |  Shift + AV / Input / RDS |  => |  Shift + CH- / |
|  Source 1 |  AV / Input / RDS |  0 |  0 |
|  1 |  1 |  - / - / => |  Shift + CH+ / |
|  2 |  2 |  - / - / => |  Guide / EPG / - / - |
|  3 |  3 |  Fa- |  Left |
|  Contrast- |  I<< / Preset- |  Fa+ |  Right |
|  Contrast+ |  >>I / Preset+ |  Vol- |  Vol- |
|  4 |  4 |  Vol+ |  Vol+ |
|  5 |  5 |  ><- |  CH- / Page- |
|  6 |  6 |  ><+ |  CH+ / Page+ |
|  Brightness- |  Down |  OO |  Sound / Title |
|  Brightness+ |  Up |  I-II |  Audio / Lang I/II |
|  7 |  7 |  [] |  Zoom / Size |
|  8 |  8 |  Mute |  Mute / Dimmer |





| | Original | Replacement | Original | Replacement |
|---|----------|---|----------|-------------|
|  | PP |  Back / Return | | |
|  | Exit |  Exit / Cancel / Clear | | |
|  | Size |  Shift + Zoom / | | |
|  | Cancel |  Shift + Exit / Cancel / Clear | | |
|  | [+] |  Info / Angle | | |
|  | Enter |  OK | | |
|  | Hold |  Stop / Hold | | |
|  | Reveal |  TV/Radio / | | |
|  | Mix |  Shift + Text / | | |
|  | Subcode |  Subtitle / EQ | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

