


























































| Original     | Replacement   | Original   | Replacement   |
|--------------|---|------------|---|
| On/Off       |  Power                 | Menu video |  D.Menu / Top            |
| Mute         |  Mute / Dimmer         | Store      |  Setup / OPT /           |
| On/Tim       |  Play / Slow           | Text       |  Text / Goto             |
| Off/Tim      |  Pause / Step / Freeze | TV/AV      |  AV / Input / RDS        |
| Txt Stop     |  Stop / Hold           | Menu       |  Menu / Home             |
| Tone-        |  << / Tune-            | Menu Up    |  Up                      |
| Tone+        |  >> / Tune+            | Info       |  Info / Angle            |
| Contrast-    |  I<< / Preset-         | Menu Left  |  Left                    |
| Contrast+    |  >>I / Preset+         | OK Enter   |  OK                      |
| Color- S.Std |  Sound / Title        | Menu Right |  Right                  |
| Menu audio   |  Audio / Lang I/II   | Menu Off   |  Exit / Cancel / Clear |
| Subt.List    |  Subtitle / EQ       | Menu Down  |  Down                  |
| Surround     |  Eject / Surround    | Back       |  Back / Return         |
| Color+ P.Std |  Picture / Format    | Volume+    |  Vol+                  |
| Txt Expand   |  Zoom / Size         | Browse     |  Smart / List          |
| Sleep Timer  |  Sleep / Timer       | Chan.Up    |  CH+ / Page+           |
| Return TV    |  TV/Radio /          | Volume-    |  Vol-                  |



| Original      | Replacement   | Original | Replacement |
|---------------|---|----------|-------------|
| Disp          |  Display / Media             |          |             |
| Chan.Down     |  CH- / Page-                 |          |             |
| 1             |  1                           |          |             |
| 2             |  2                           |          |             |
| 3             |  3                           |          |             |
| 4             |  4                           |          |             |
| 5             |  5                           |          |             |
| 6             |  6                           |          |             |
| 7             |  7                           |          |             |
| 8             |  8                           |          |             |
| 9             |  9                           |          |             |
| Guide -/-- 1. |  Guide / EPG / -/--         |          |             |
| 0/10          |  0                         |          |             |
| 2.Fav P/C 2.  |  Fav / Marker / PC         |          |             |
| Red           |  Red / Netflix / Search    |          |             |
| Green         |  Green / APP / Repeat      |          |             |
| Yellow        |  Yellow / YouTube / Repeat |          |             |

| Original       | Replacement   | Original | Replacement |
|----------------|---|----------|-------------|
| Blue           |  Blue / Prime Video / Random |          |             |
| Update         |  Shift + Play /              |          |             |
| Reveal         |  Shift + Pause / Step /      |          |             |
| Nicam/Mono     |  Shift + Audio / Lang I/II   |          |             |
| 4.# 16:9       |  Shift + Picture / Format    |          |             |
| Store Text     |  Shift + Setup / OPT / Tools |          |             |
| Rotate Text    |  Shift + Text /              |          |             |
| Level L        |  Shift + Left                |          |             |
| Level R/Woofer |  Shift + Right               |          |             |
| Audio+         |  Shift + Vol+                |          |             |
| Game Coo       |  Shift + Smart / List        |          |             |
| Bright+ Mode   |  Shift + CH+ /              |          |             |
| Display        |  Shift + Display / Media   |          |             |
| Bright- Sys    |  Shift + CH- /             |          |             |
| 3.*            |  Shift + 3                 |          |             |
| Search         |  Shift + Red / Netflix /   |          |             |

