































































































Original		Replacement		Original		Replacement	
	Power		Power		7		7
	Display		Display / Media		8		8
	Mute		Mute / Dimmer		9		9
	TV		TV/Radio /		Recall		Back / Return
	AV		AV / Input / RDS		0		0
	Scart		Shift + 7		Enter		Fav / Marker / PC
	PC		Shift + Fav / Marker / PC		Menu		Menu / Home
	Sleep		Sleep / Timer		Up		Up
	EPG		Guide / EPG / /--		TTX/MIX		Text / Goto
	CH.List		Smart / List		Left		Left
	SRS		Sound / Title		OK		OK
	1		1		Right		Right
	2		2		Wide		Picture / Format
	3		3		Down		Down
	4		4		MPX		Setup / OPT /
	5		5		Vol+		Vol+
	6		6		CH+		CH+ / Page+





Original		Replacement		Original		Replacement	
	Vol-		Vol-				
	CH-		CH- / Page-				
	Red		Red / Netflix / Search				
	Green		Green / APP / Repeat				
	Yellow		Yellow / YouTube / Repeat				
	Blue		Blue / Prime Video / Random				
	Index		Info / Angle				
	Subtitle		Subtitle / EQ				
	Subpage		Audio / Lang I/II				
	Reveal		Exit / Cancel / Clear				
	Size		Zoom / Size				
	Hold		Stop / Hold				

