

























































Original		Replacement		Original		Replacement	
	Mute		Mute / Dimmer		Vol-		Vol-
	Power		Power		Up		Up
	1		1		P+		CH+ / Page+
	2		2		Vol+		Vol+
	3		3		Right		Right
	4		4		P-		CH- / Page-
	5		5		Down		Down
	6		6		Call		Fav / Marker / PC
	7		7		Time		Sleep / Timer
	8		8		Fresh		Subtitle / EQ
	9		9		View		Smart / List
	--		Guide / EPG / --		Mode		Picture / Format
	0		0		Back		Back / Return
	PIP		Zoom / Size				
	Menu		Menu / Home				
	TV/AV		AV / Input / RDS				
	Left		Left				

