

















































Original	Replacement
 Tv/AV	 AV / Input / RDS
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 PSM	 Guide / EPG / -/--
 0	 0
 SSM	 Fav / Marker / PC
 I/II	 Audio / Lang I/II
 *	 Sleep / Timer
 Picture	 Picture / Format

Original	Replacement
 Menu	 Menu / Home
 Sound	 Sound / Title
 Up	 Up
 PR+	 CH+ / Page+
 Vol+	 Vol+
 Right	 Right
 Vol-	 Vol-
 Left	 Left
 OK	 OK
 Down	 Down
 PR-	 CH- / Page-
 PIP	 Zoom / Size
 Mute	 Mute / Dimmer
 Red/PIP PR-	 Red / Netflix / Search
 Green/ PIPPR+	 Green / APP / Repeat
 ARC	 Display / Media
 Blue/PIP Input	 Blue / Prime Video / Random



