

















Original	Replacement
	Power
	Mute
	1
	2
	3
	4
	5
	6
	7
	8
	9
	ECO
	0
	EPG
	Vol+
	CH+ / Page+
	Vol-

Original	Replacement
	Smart Key
	CH- / Page-
	Info / Angle
	AV / Input / RDS
	Back / Return
	Menu / Home
	Exit / Cancel / Clear
	Up
	Left
	OK
	Right
	Rec / Rec Mode
	Down
	Sleep / Timer
	Text / Goto
	Subtitle / EQ
	Smart / List





Original	Replacement	Original	Replacement
	Fav		Fav / Marker / PC
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue / Lang		Shift + Blue / Prime
	Blue / Lang		Blue / Prime Video / Random

