
























| Original | Replacement |
|---|--|
|  TV System |  Shift + TV/Radio / Program |
|  Power |  Power |
|  Audio |  Audio / Lang I/II |
|  Subtitle |  Subtitle / EQ |
|  Recall |  Shift + Back / Return |
|  A-B |  Shift + 0 |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  Text |  Text / Goto |
|  0 |  0 |

| Original | Replacement |
|---|---|
|  Edit |  Fav / Marker / PC |
|  Pause |  Pause / Step / Freeze |
|  Rec |  Rec / Rec Mode |
|  Up / CH+ |  Shift + Up |
|  Up / CH+ |  Up |
|  Play |  Play / Slow |
|  Left |  Left |
|  Enter |  OK |
|  Right |  Right |
|  Back |  Back / Return |
|  Down / CH- |  Shift + Down |
|  Down / CH- |  Down |
|  Home |  Menu / Home |
|  Stop |  Stop / Hold |
|  Favor/Vol + / Sel |  Vol+ |
|  Source |  AV / Input / RDS |
|  ← Skip |  << / Tune- |





| Original | Replacement |
|--|---|
|  Favor/Vol - / Load |  Vol- |
|  Time Shift |  Shift + Sleep / Timer |
|  Skip -> |  >> / Tune+ |
|  Timer Rec |  Sleep / Timer |
|  EPG |  Guide / EPG / -/-- |
|  Dimmer |  Shift + Mute / Dimmer |
|  DTV |  Shift + 2 |
|  Red / <<< |  Shift + Red / Netflix / Search |
|  Red / <<< |  Red / Netflix / Search |
|  Green / >>> |  Shift + Green / APP / Repeat |
|  Green / >>> |  Green / APP / Repeat |
|  Yellow / <<< |  Shift + Yellow / YouTube / Repeat |
|  Yellow / <<< |  Yellow / YouTube / Repeat |
|  Blue / >>> |  Shift + Blue / Prime / Random |
|  Blue / >>> |  Blue / Prime Video / Random |
|  Zoom |  Zoom / Size |
|  Eject / Goto |  Eject / Surround |

| Original | Replacement |
|---|---|
|  Display |  Display / Media |
|  TV HMR |  TV/Radio / |
|  Mute |  Mute / Dimmer |
|  LAN |  Sound / Title |
|  USB |  Shift + 8 |
|  HDD |  Shift + 7 |

