







































































Original	Replacement	Original	Replacement
 Power	 Power	 0	 0
 Display	 Info	 Recall	 Pre Ch
 Mute	 Mute	 Enter	 Guide
 TV	 TV/R	 Menu	 Menu
 AV	 AV	 TTX/MIX	 Text
 Scart	 Smart	 Wide	 3D
 PC	 Media	 MPX	 Options
 Sleep	 Sleep	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 CH+	 Ch +
 8	 8	 CH-	 Ch -
 9	 9	 Red	 Red





Original		Replacement		Original		Replacement	
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Subtitle		Subt				
	Index		List				
	Subpage		D. Menu				
	Reveal		Dual				
	Size		Format				
	Hold		Eject				

