


























































































Original		Replacement		Original		Replacement	
	Power		Power		CH-		Ch -
	Mute		Mute		P.Mode		Shift + Format
	1		1		S.Mode		Shift + Dual
	2		2		Source		AV
	3		3		Menu		Menu
	4		4		Exit		Exit
	5		5		Up		Up
	6		6		Down		Down
	7		7		Right		Right
	8		8		Left		Left
	9		9		OK		Ok
	0		0		List/Rec		List
	FAV		Pre Ch		USB/Media		Media
	Info		Info		SOS/Help		Options
	Vol+		Vol +		EPG/Guide		Guide
	Vol-		Vol -		I-I/Goto		Smart
	CH+		Ch +		Rec		Rec





Original		Replacement		Original		Replacement	
	Stop		Stop		√		TV/R
	Play		Play		Recall		Back
	Pause		Pause				
	I<<		I<<				
	<<		<<				
	>>		>>				
	>>I		>>I				
	Red/Timer		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	4:3/16:9		Format				
	Subt.		Subt				
	Lang		Dual				
	Sleep		Sleep				
	Zoom		Eject				
	Text		Text				

