



















































Original		Replacement		Original		Replacement	
	Power		Power		Green		Green
	Play		Play		Yellow		Yellow
	Pause		Pause		Blue		Blue
	<<		<<		CH+		Ch +
	>>		>>		CH-		Ch -
	I<<		I<<		Vol+		Vol +
	>>I		>>I		Vol-		Vol -
	Stop		Stop		Source		AV
	Rec		Rec		Menu		Menu
	Tv/TXT		Text		DVB		Smart
	Cancel		Back		Exit		Exit
	Reveal		D. Menu		Up		Up
	Hold		Options		Down		Down
	Size		Eject		Right		Right
	Subpage		Shift + Subt		Left		Left
	Index		Info		OK		Ok
	Red		Red		1		1





Original	Replacement
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/--	SHIFT + -/-- Guide
Recall	FAV PRE-CH Pre Ch
Picture	SHIFT + PICTURE FORMAT Shift + Format
Sound	SHIFT + SOUND DUAL Shift + Dual
Nicam/A2	APP MEDIA Media
Mute	MUTE Mute
Sleep	PROG SLEEP Sleep
Tv/Radio	SEARCH TV/R TV/R

Original	Replacement
FAV	SHIFT + FAV PRE-CH Shift + Pre Ch
FAV+	SHIFT + + CH Shift + Ch +
FAV-	SHIFT + CH - Shift + Ch -
Subtitle	AD SUBT Subt
Pic Format	PICTURE FORMAT Format
Language	SOUND DUAL Dual
EPG	-/-- GUIDE Guide
Text	DISC NAV LIST List
Display	ECO 3D 3D

