







































Original	Replacement
	
Power	Power
	
Mute	Mute
	
1	1
	
2	2
	
3	3
	
4	4
	
5	5
	
6	6
	
7	7
	
8	8
	
9	9
	
0	0
	
i	Info
	
EPG	Guide
	
Vol+	Vol +
	
Vol-	Vol -
	
Menu	Menu

Original	Replacement
	
[=]	Text
	
P+	Ch +
	
P-	Ch -
	
Up	Up
	
Down	Down
	
Right	Right
	
Left	Left
	
OK	Ok
	
Exit	Exit
	
OPT	Options
	
Red	Red
	
Green	Green
	
Yellow	Yellow
	
Blue	Blue
	
MSG	Format
	
Tv/STB	Media
	
Nothing	Smart





Original	Replacement
 Tv/R	 TV/R

Original	Replacement

