





































Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--/X/Prefe	 Guide / EPG / -/--
 →/Salir/AV	 Exit / Cancel / Clear
 Up	 Up
 Left	 Left
 OK/Select	 OK
 Right	 Right

Original	Replacement
 Down	 Down
 Guia	 Shift + Guide / EPG / -/--
 Piloto	 Display / Media
 Serv	 Fav / Marker / PC
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 E	 Setup / OPT /
 Mute	 Mute / Dimmer
 +/Info	 Info / Angle
 Perso	 Text / Goto
 Tv/Sat	 TV/Radio /





Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 ZAP+	 CH+ / Page+
 Left	 Left

Original	Replacement
 Right	 Right
 Vol-	 Vol-
 Down	 Down
 ZAP-	 CH- / Page-
 Menu	 Menu / Home
 Guia	 Shift + Guide / EPG / -/-
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 E	 Setup / OPT /
 Mute	 Mute / Dimmer

